

Pi对应Firstack互换型号

序号	PI型号	Firstack型号	说明	备注
1	2SP0435T2G1-17	2FSC0435+A.3	PI引脚3.1mm	
2	2SP0435T2H0-17	2FSC0435+A.3	PI引脚2.54mm	
3	2SP0115T2Bx-12	2FSD0115T12A1	pin-pin	2SP0115T2B0-12
4	2SP0115T2Cx-12	2FSD0115T12B1	pin-pin	2SP0115T2C0-12
5	2SP0115T2Bx-17	2FSD0115T17A1	pin-pin	
6	2SP0115T2Cx-17	2FSD0115T17B1	pin-pin	2SP0115T2C0-17
7	2SP0320T2A0-12	2FSD0320T12A1	pin-pin	
8	2SP0320V2A0-12	PM0538NT12A1	pin-pin	
9	2SP0320S2A0-12	PM0538S	pin-pin	
10	2SP0320T2B0-12	2FSD0320T12A1	pin-pin	
11	2SP0320V2B0-12	PM0538NT12A1	pin-pin	
12	2SP0320T2C0-12	2FSD0320T12B1	pin-pin	
13	2SP0320T2D0-12 (C0-EMI)	2FSD0320T12B1	pin-pin	
14	2SP0320V2D0-12 (A0-Rohs)	PM0538NT12A1	pin-pin	
15	2SP0320T2A0-17	2FSD0320T17A1	pin-pin	
16	2SP0320V2A0-17	PM0538NT17A1	pin-pin	
17	2SP0320T2C0-17	2FSD320T17B1	pin-pin	
18	2SP0320T2D0-17 (C0-EMI)	2FSD0320T17B1	pin-pin	
19	2SP0320V2D0-17 (A0-Rohs)	PM0538NT171	pin-pin	
20	1SP0635V2M1-33	1FSD08110	电源供电端子不同，驱动协议一致	
21	1SP0635D2S1-33	HMV10126	FSD是一拖二，PI是主从版	
22	1SP0335V2M1-45	HV1027P	电源端子不兼容	
23	1SP0340V2M0	1FSD08110	无从板，并联选1FSD215	
24	IS05125I	FPS08-15K	电源端子不兼容	
25	2SP0320V2A0-17	PM0538-N-B17-60901000-C	水平光纤头HFBR1521/HFBR2521	
26		PM0538-N-B17-60901000-C	水平光纤头HFBR1521/HFBR2521	